


Set up and use your R717 Hotspot – Quick Steps

1. Insert the Battery

- Remove the back cover using the thumb catch on the bottom edge of the hotspot.
- Align the battery's contacts with those inside the battery compartment and gently press down until the battery is seated.
- Replace the back cover.

2. Charge the Battery

- Insert the small end of the USB cable into the micro-USB charging port on the right side of the hotspot.
- Plug the charging adapter into a standard AC power outlet.



3. Get Ready

- Make sure you are in an area covered by your service provider.
- Make sure the device you are trying to connect to your Hotspot has its Wi-Fi (wireless network connection) mode turned on.

4. Connect to Your Hotspot

- Turn on your hotspot and your Wi-Fi-enabled device (computer, tablet).
- Use the Power button on your hotspot to scroll through screens to display your hotspot's name and password.
- Open the Wi-Fi application or Wi-Fi controls on the device that you want to connect to your hotspot.
- Enter the hotspot's name and password to connect your device to the hotspot.

Connection Issues? Call 1-877-460-LINC (5462)

Southern Linc's Customer Solutions team can assist you.

See the complete user guide at <https://www.southernlinc.com/lte/tips-tricks.aspx>.